

SUMMARY

iAiming Application is a free service software for iAiming Scope. To meet diverse demand of users, the app realizes the image sync transmission and real-time control to scope by connecting the scope with mobile device.

FUNCTION


- Live video recording and still photo capture, adjust image settings;
- View the device information;
- Local files and storage files operation;
- Information about the scope, firmware updates and Language selections.
- Live stream

OPERATING ENVIRONMENT

iAiming App requests Android 7.0 and iOS 10.0 or higher version for mobile device.

INSTALL IAIMING APP

User can download iAiming APP in AppStore or Google Play.



PAIR SCOPE TO MOBILE DEVICE

STEP 1.

Turn on **WIFI** function in menu settings of your device.




STEP 2.

Tap **Settings** on your mobile device. Select **WLAN** option **On**.

STEP 3.

Search on the available network list and select the name of the scope with its model name and series number (for example, iA617-2101074).




STEP 4.

Type in **WIFI password**. Default password is **87654321**. User can check the password in scope **General Settings**→**WIFI password**.

STEP 5.

Tap iAiming App. When successfully connected to mobile device, the scope model name and connect status **“Connected”** are shown under the device icon.



Tips: If the device status unrefreshed timely, please tap **Live Video** then back to homepage, the connected device will be shown.



CONTROL THE SCOPE BY USING A MOBILE DEVICE


LIVE VIDEO

Press **Live Video** button to view the live image of scope



PARAMETERS

Select **Palette** option. You can choose either a **White, Black, Ironbow, Glowbow, Sepia, Red hot, Green hot** setting




Select **Image Mode 1** or **Model 2** for scope.

Mode 1: High contrast, if you want target conspicuous, you can select this mode.


Mode 2: Average grey color distribution, more suitable for sky-land scene or high temperature difference scene.



Select **Reticle type** option. You have 6 reticle types for choose.



Select **Brightness** option. Adjust slide bar to set **Brightness** for image.



Select **Contrast** option. Adjust slide bar to set **Contrast** for image.



ZOOM


Select **Zoom** option. Adjust slide bar to **Zoom in** or **Zoom out** the image.




PHOTO / VIDEO

Select **Video** option in **Video** menu, press the red button to start recording.

Press again to stop. The recording video file is saved at local file automatically.



Select **Photo** option in **Video** menu and press the grey button to take photo of image. The photo is saved at local file instantly.



LIVE STREAM

STEP 1.


Tap **Live Stream** button on the home screen to go to live stream function.

STEP 2.

Input live stream info.

Turn off the WIFI network and turn on the Hotspot of mobile device. Make sure the hotspot name and password inputted same as the info on your mobile device, otherwise, the device can not connect to the mobile hotspot.


Then click **Next**.



STEP 3.

Input your account info of selected live stream platform.

Select Facebook or YouTube to connect your account. Follow the steps to input your account info to log on the platform.



STEP 4.

After the successful connect to your Facebook/YouTube account and get your stream link on the platform. Copy the message and back to the APP, then paste the stream link message on the APP.


STEP 5.

Tap **Start stream** to begin live streaming.

Tips: Please make sure the Auto refresh function of scope is turned off before using the Live Stream function.

FILE

Tap **File** to manage the files on the local mobile phone and scope device.




The file can be selected, viewed, shared and deleted for user purpose.




Tips: To share the file, please disconnect the WIFI and use the public network.

The file needs to be converted for sharing. Please allow and click Convert and share to next share



The **file** locates in Device can be selected, viewed, downloaded for user purpose.

Press **Download** to download it from device to phone. After downloaded, the file can be managed as the files on your phone.




Tips: If user need to delete the downloaded file, please carefully select the file location. When you select delete on phone, the file on device retained, which can be downloaded again. When you select delete both phone and device, the file can no longer be recovered.




SETTINGS

Press **Settings** button to view the **Privacy Policy**, **License Agreement**, **APP Version**, **check Update**, **Contract support** and select **Language**.



DEVICE OPERATION


Press the device icon to view the device information including **Connection Status**, **SN**, **HW**, **SW**, **FPGA** and **ARM** version.



FIRMWARE UPDATE

STEP 1.

Press **Firmware update** and select the firmware type you would like to update.




STEP 2.

Press **Check latest version**.



Tips: before check, disconnect device WiFi and make the phone connected to network.

If new firmware found, the latest firmware version displays. If no new firmware found, it will prompt that the device firmware is the latest version.



STEP 3.

Select **Download new firmware**. After downloading, connect device WiFi and press **Update now** to update.



Tips: during the updating, do not exit the APP.

STEP 4.

After update, reboot the device. The device will work as new firmware.

DELETE DEVICE

Tap **Delete your device** in **My device** page to delete the selected device.